

DRIFT PRO

Fogstar Drift 460Ah 12V Specification
Powered by EVE Prismatic

FOGSTAR DRIFT PRO 460AH



SPECIFICATIONS	
CELL TYPE	LF230K-54174/3.2V
CELL CONFIGURATION	4S2P
NOMINAL CAPACITY	460AH
ENERGY	5888WH
CELL CHEMISTRY	LITHIUM IRON PHOSPHATE
CELL NOMINAL VOLTAGE	3.2V *8 (12.8V)
CYCLE LIFE	4500 CYCLES @ 80%
MAXIMUM DISCHARGE	300A
MAXIMUM CHARGE CURRENT	230A (0.5C)
STANDARD CHARGING CURRENT	92A (0.2C)
NOMINAL VOLTAGE	12.8V
STANDARD CHARGING VOLTAGE	14.4V
MAXIMUM CHARGING VOLTAGE	14.6V
DISCHARGE CUT OFF VOLTAGE	10V
DISCHARGE TEMPERATURE RANGE	-20°C ~ 55°C
CHARGE TEMPERATURE RANGE	0°C ~ 55°C
HEATING FUNCTION	0°C ~ 10°C
STORAGE	-20°C ~ 45 °C (1 MONTH) 0°C ~ 35°C (3 MONTHS)
MEASUREMENTS	HEIGHT 280MM (±1.0MM) LENGTH 531MM (±1.0MM) THICKNESS 205MM (±1.0MM)
WEIGHT	47.3KG
HOUSING MATERIAL	METAL
CONFORMITY	UN38.3, ROHS, CE, UL, UKCA



UN38.3

JBD BMS	
MAXIMUM DISCHARGE	300A
TEMPERATE PROTECTION	YES
OVERCURRENT PROTECTION	YES
OVERDISCHARGE PROTECTION	YES
MAX CHARGING CURRENT	300A

ACTIVE BALANCER	
EQUALISER	2A
VOLTAGE ACQUISITION RANGE	1 V – 5V
ACCURACY	± 3MV
BLUETOOTH COMMUNICATION	YES
DIMENSIONS	160MM x 100MM x 20MM

DRIFTPRO

Storing your Battery

We strongly suggest your batteries are stored at room temperature, charged to about 30% to 50% of capacity. We recommend that batteries be charged once every three months to prevent over discharge.

Battery Performance

Because Lithium Iron Phosphate batteries utilise a chemical reaction, battery performance will deteriorate over time even if stored for long periods of time without being regularly used.

In addition, if the various usage conditions such as charge, discharge, ambient temperature, etc. are not maintained within the specified ranges, the life expectancy of the battery may be shortened, or the device in which the battery is used may be damaged by electrolyte leakage.

If the batteries cannot maintain a charge for long periods of time, even when they are charged correctly, this may indicate it is time to change the battery.

Battery Safety

- Do not disassemble your battery.
- Do not short the battery.
- Do not store your batteries in direct sunlight.
- Store the battery in a cool and well ventilated area.
- Keep batteries away from flammable objects and materials.
- Keep batteries away from static electric charges.
- Keep out of reach from animals and children.
- Do not immerse your battery in water.
- Do not crush, incinerate or modify your battery.
- Only use batteries within the manufacturers specifications.
- Recycle your batteries correctly.

Battery Series and Parallel Mode

All 12V batteries can be connected either four (4) in series OR four (4) in parallel. Our 24V models can be connected four (4) in parallel OR two (2) in series.

Battery Heating

This battery has a built-in heater that heats the battery to 5C to enable charging at low temperatures.

The Drift heating pads are only activated when the battery is being charged, and are only powered by the incoming charge current, not the battery itself. If you put the battery on charge in cold temperatures, it will heat the battery first, and then allow current through to the battery when the temperature is safe enough to do so.

Charging

Your battery should be charged using a lithium iron phosphate battery charger.

Bulk Charge : 14.2V - 14.4V

Float Charge :13.5V - 13.8V

Charging Current : up to 300A

Battery Warranty

- Fogstar offers a 10 year warranty on all Fogstar Drift Leisure batteries.
- Warranties only apply to the original owner and are non-transferrable.
- Fogstar will verify your purchase prior to processing any warranty claims or returns.
- Please contact us at customerservice@fogstar.co.uk as soon as you encounter any issues.
- Our warranty does not cover items that have been damaged due to gross negligence, normal wear and tear, damage due to accident or collision, abuse or incorrect installation.

Download the Fogstar Drift App

As a Fogstar customer, you'll also get the use of our fantastic Fogstar Drift App. Our App has been custom built to connect directly with the BMS, allowing you to manage and maintain the health of the battery at all times.

The Fogstar Drift app is free to download on both Android and iOS.

You can find out more about the Fogstar Drift App at our dedicated Fogstar Drift website www.fogstar-drift.co.uk.

JK Active Balancer

Because your battery contains matched and balanced Grade A EVE cells, you should not have to use your Active Balancer often. We recommend plugging the device in every three (3) to six (6) months, for two (2) to three (3) cycles (depending upon levels of cell disparity).

Do not leave the device plugged in indefinitely. All Active Balancers (external or built in) have a large self consumption of >1Ah per day on average - even when not balancing.

